### **Compiler License Activation Guide**

## **mikroBasic** PRO for FT90x LICENSE ACTIVATION CARD



This card contains information about your mikroBasic PRO for FT90x compiler license.

Activation Key

on the back

# instructions inside

## Activating The Compiler License

In order to use all features of MikroElektronika Compilers for FT90x microcontrollers an activation must be performed. This document briefly explains the terms related to the compiler license, and guides the customer through the software activation procedure.

#### Q. What is the MikroElektronika Compiler License?

MikroElektronika Compiler license is the permission to use MikroElektronika Compiler with all it's features. License is granted to the customer by MikroElektronika as a licensor. The customer must purchase the license rights and then apply a License Activation Key to unlock the Compiler and remove the Demo Limit. The customer is bound to comply with the Terms of Usage defined in the Software License Agreement.

#### Q. What is the Activation Key?

The Activation Key is a unique sequence consisted of 20 characters and numbers. It is delivered to the user upon purchase. The Activation Key is located at the back of the License Activation Card. At all times, Activation Key remains the property of MikroElektronika.

#### **Q. What is Software Activation?**

Activation is a process of validation of the Activation Key. Successful Activation removes the Demo Limit and unlocks all software features.

#### **Q. How to Perform the Activation?**

1. Download and install the desired Compiler for FT90x from http://www.mikroe.com/FT90x/compilers/ or from the Product DVD.

- 2. Start the application. Open Help menu and click the Software Activation option.
- 3. Enter the Activation Key in the Key fields. Type in your general information in the fields below as well.
- 4. Click the **Activate** button.

<u>H</u> el	p	Software Activation	X
0	He <u>l</u> p F1	Please locate the Activation key for your copy of mikroC PRO for	r O
	Migration Document	FT90X software and enter the filed below:	2000-3000 HIGH SCOP
0	Check For Updates	Key:	Activation Key is located on the back of the License
G	m <u>i</u> kroElektronika Web Page	Name: User	Activation Card that came along with the software package.
•	mi <u>k</u> roElektronika Support Forums	Company: company	In case of electronic license delivery, the
۲	Libstock Developer Community	Activate	Activation Key can be found in the <b>E-mail</b> delivered to you upon
Ø	Software Activation	Request time trial License. I'm ready to buy the license. Go shopping.	purchase.
0	<u>A</u> bout	I own the license, but didn't get the key. Request the License. FAQ	

Figure 1-1: Help menu contains the Software Activation item.

#### **Q. What is Software Registration?**

Registration is a process which establishes a unique connection between MikroElektronika as a Licensor and the customer as a Licensee. By registering his copy of the Compiler, the customer is granted access to Live Updates, Technical Support and other benefits.

#### Q. Why should I keep my Activation Key a secret?

Publishing, renting, public performance, broadcasting or otherwise disclosing the Activation Key to a third party is strictly prohibited. By doing so customer may loose all benefits granted by registration. In case of severe violations of Software License Agreement, MikroElektronika reserves the right to delicense the customer and request the removal of the Activation Key from the customer's computer.



If you want to learn more about our products, please visit our website at www.mikroe.com If you are experiencing some problems with any of our products or just need additional information, please place your ticket at www.mikroe.com/support If you have any questions, comments or business proposals, do not hesitate to contact us at office@mikroe.com

FT90x Compiler License Activation Guide v100

